CARE AND REPLACEMENT OF WICK

Always keep wick extended ⅛-inch above the nozzle so that flame will burn easily Trim off charred or frayed edges regularly

When flame dies quickly your RONSON needs re-fueling. When wick fails to burn properly after re-fueling it should be replaced. Pull out old wick – do not attempt to unscrew wick-nozzle, remove old cotton wool packing. Insert new wick by pushing it through wick-nozzle, pull end of wick out of filler screw hole, pack cotton wool tightly inside case and insert end of wick. Wick must be mingled with cotton wool or it will not be properly supplied with fuel. For best results change wick every few months.